

Heavy Duty Anchor Kit Installation Instructions.



Kit Contains:

- 4x Heavy Duty Steel Pegs
- 4x Straps
- 1x Instruction Sheet



Instructions:

1. Use a large hammer to bang the four heavy duty steel pegs into the ground. Orientate the peg so the hook is facing away from the trampoline also angle the peg slightly away from the trampoline (approx 10°). Now bang the peg about two thirds of the way in. *Please note, for the round trampoline models (SF40 & SF72) place the pegs equidistant from one another around the trampoline. For the Squircle and Oval Models (SF60, SF68, & SF80) place one peg at each corner of the trampoline. We also suggest you place the pegs close beside the legs so that they blend in with the trampoline. For non-Springfree trampolines ensure the pegs are equally spaced around the trampoline and the strap is secured to the frame, rather than the legs.*
2. Place the long end of the strap (*identifiable by the white tag*) around the frame of the trampoline, making sure the clip is facing outwards, then thread the short end of the strap through the hole at the long end, and pull all the way through so that the long strap is tight around the frame (*in a lasso type fashion*). **See Figure 1.**
3. Hook the loop at the end of the short end of the strap over the hook of the peg and hammer the peg the rest of the way down so that the top of the peg is level with the ground (the hook will be slightly in the ground also), this will ensure the strap cannot slip off.
4. Pull the loose end of the long strap upwards, so that it is comfortably firm, it does not need to be super tight. **See Figure 2.**

Please note: that in the event of extremely severe wind warnings, eg. 80km/hr or more we strongly recommend taking down the flexinet enclosure, additional to having the anchor kit installed.

Figure 1:



Figure 2

